

SELF-DIAGNOSIS FOR CITROEN XSARA PICASSO

Dear customer,

we would like give you some hints about the diagnostic features available on Citroen Xsara Picasso models. As a matter of fact, we've recently received some reports of "no connection" with some systems on these cars. In order to correctly understand the problems, the following must be taken into consideration:

In some cases it may be difficult to couple the ECU031 cable to the EOBD diagnostic socket mounted on the Citroen Xsara Picasso. This socket is not fully compliant to the ISO 15031-3 standard, which specifies dimensions and tolerances of both the diagnostic connector and diagnostic sockets.

When inserting the ECU031 cable, it *may* happen that the scan tool turns on, but there's still no contact with the diagnostic lines. In order to establish a perfect connection, you should verify the perfect alignment of plug and socket, and check the absence of any play between them. **Always check this connection in any case of missing communication between the FAST scan tool and the ECU of the vehicle under test.**

We hope that you may find these information useful. Do not esitate to contact us for any doubt or question!

After Sales Department's Technical Staff